

red-y smart series product information

Thermal Mass Flow Meters and Controllers for Gases



Reliable and accurate:

Thermal Mass Flow Meters and Controllers

Reliable technology and standardized interfaces make the red-y smart series thermal mass flow meters and controllers particularly suitable for measurement and control in gas delivery systems and plant engineering applications.

Accurate measurement

The devices offer high accuracy and a wide dynamic range.

- 2 instrument versions:
- <Standard> and <Hi-Performance>

Accuracy up to ± 0.3% of full scale + ±0.5% of reading

Turndown ratio 1:100

Extended turndown ratio on request

Analog & digital: 2 in 1



The flow meters and controllers make use of the latest CMOS technology and have a digital (Modbus RTU) and analog interface as standard

Safe & fast control



The controller uses a tightly sealed control valve with leak rate less than 1x10⁻⁶mbar I/s He. The fast control response of approx. 300 ms significantly reduces the setting time

Operating status indication



The instruments offer an inbuilt LED status indication

Options



Built-in display

Display of flow rate, total and measuring unit. Defining a set point (controller only)





Multigas

One meter or controller can be used for up to 10 different gases or gas mixtures



Profibus

The instruments are available with Profibus interface: DP-V0 & DP-V1 protocols



Industrial Ethernet

Two industrial ethernet protocols *Profinet RT* and EtherCAT are available





<get red-y> software

Efficient device management with the free <get red-y> software:

- » View flow rate & temperature
- **Change set points**
- Select measured gas
- Visualization of measured data
- » Adjusting control parameter

Optional modules <get red-y> software:

- **Datalogging**
- Gasmixing
- » Adjustment/Calibration

3-year warranty*



High-quality components ensure long and trouble-free operation

*does not apply to calibration, options and accessories





Fig. 2 Configuration of the devices via the free get red-y software

Fig. 1 red-y smart controller GSC with

Industrial Ethernet interface at the top of the device

High-quality technology offers maximal value for any application

Through the application of **high-precision MEMS technology** (CMOS sensors), the thermal flow meters and controllers from Vögtlin Instruments GmbH set new standards in terms of response characteristics and measuring accuracy, and are characterized by maximum convenience:




Fig. 3 High-tech in a very compact design: The flow meters and controllers use advanced MEMS technology

- » Standardized signals enable simple connection to control systems
- » Measurements are insensitive to pressure and temperature changes
- All devices are calibrated with real gas. This ensures high accuracy and reproducibility.
 The calibration is traceable to the METAS standard (Federal Office of Metrology, Switzerland)
- » Meters and controllers are easy to service and maintain
- » The devices have minimal pressure drop
- A full range of accessories is available:Cables, fittings, etc.
- » <Plug & control» with the free software <get red-y»: Simple access via any PC (no additional electronic equipment required)
- » High quality: All flow meters are produced and calibrated at our European production center in Germany

Flexibility in mixing processes and consumption measurement

Devices with high measuring accuracy and stable control characteristics are important for ensuring precise and consistent quality of gas mixtures.

The thermal mass flow meters and controllers from Vögtlin offer unbeatable technological performance and cost-effectiveness.



Wide range of accessories - immediately ready for operation



Fig. 4 Process Control Unit PCU-10

Connection cables, power supplies

Optimal range of cables and power supply units for fast integration of flow meters and controllers:

Cables for communication with PC (USB), cables for analog communication, power supply (24 Vdc)

Display and control devices

Permit the operation of up to 10 flow meters and controllers with predefined process recipes.

Fittings, filters

All flow meters and controllers are available with fittings and filters. Contact our sales department for more information.

Technical Data <red-y smart series>

Instrument types







smart meter GSM	
Thermal mass flow meter	

ermal mass flow meter Thermal mass flow controller

OI	Ħ١	И	v	6	re	٤i	o	r	1
•	31	ш	·	c	ш	ш	v	ш	ı

For customer-specific requirements

Instrument versions		
mstrument versions		

<standard></standard>	Accuracy:	± 1.0 % of full scale ⁽¹⁾
The economic solution	Turndown ratio:	1:50 (available on request up to 1:1000)
<hi-performance></hi-performance>	Accuracy:	\pm 0.3 % of full scale + \pm 0.5% of reading $^{(1)}$
With highest accuracy and turndown ratio	Turndown ratio:	1:100 (available on request up to 1:1000)
(available for GSM < 200 ln/min / GSC < 150 ln/min (air))	¹An additional error o	f ±0.25% may apply for analogue signals

smart controller GSC

Measuring ranges

(Air/Full scale freely selectable)	Туре	Measuring range (air)		Connection
red-y smart meter GSM Meter	GSM-A GSM-B GSM-C GSM-D	from 0 25 mln/min from 0 600 mln/min from 0 6 ln/min from 0 60 ln/min	to 0 600 mln/min to 0 6000 mln/min to 0 60 ln/min to 0 450 ln/min	G¼" G¼" G½" G½"
red-y smart controller GSC Controller	GSC-A GSC-B GSC-C GSC-D	from 0 25 mln/min from 0 600 mln/min from 0 6 ln/min from 0 60 ln/min	to 0 600 mln/min to 0 6000 mln/min to 0 60 ln/min to 0 450 ln/min	G1/4" G1/4" G1/4" G1/2"

	GSC-C GSC-D	from 0 6 In/min from 0 60 In/min	to 0 60 In/min to 0 450 In/min	G1/4" G1/2"
Performance data				
Media (real gas calibration)		N2 ⁽²⁾ , He, Ar, CO2, H2, CH4, calibrated with air	C3H8 (other gases and gas	s mixtures on request)
Response time	,	M): \pm 80ms ⁽³⁾ ; Controller (GS on device configuration & according	,	0% of range under optimized conditions
Repeatability	± 0.2% of f	ull scale (according to SEM	l standard E56-0309)	
Longterm stability	< 1% of me	asured value / year		
Power supply	24 Vdc (18	– 30 Vdc), 15 Vdc on reque	est	
Current consumption Standard	Meter (GSI) 4DV = Double	,	(GSC): max. 250mA (GSC wi	th valve type xDV ⁽⁴⁾ max. 490mA)
Current consumption Profinet RT/EtherCAT	Meter (GSI	M): max. 125mA; Controller (GSC): max. 340mA (GSC wit	h valve type xDV ⁽⁴⁾ max. 560mA)
Operation pressure	0.2 – 11 ba	r a (GSC with valve type 4.5	5/EQP and 8/EQP DV ⁽⁴⁾ up to	max. 8 bar a)
Temperature (environment/gas)	0 – 50°C			
Materials	Anodized	aluminium, optional stainle	ss steel electropolished	
Seals	FKM, EPDI	M, optional FFKM		
Pressure sensitivity	< 0.2% / ba	ar of reading (typical N2)		
Temperature sensitivity	< 0.025% F	S measuring range type /	°C	
Warm-up time	<1 sec. for	full accuracy		
Integration				
In-/Output signals analog	020 mA,	420 mA, 05 V, 15 V, 010	0 V, 210 V	
In-/Output signals digital		odbus RTU (Slave); Lab Vie option: ProfiBus DP-V0, DF	ew-VIs available P-V1/Profinet RT/EtherCAT	
Process connection	,	o ⁽⁵⁾ female) up to 60 ln/min, o dard Pipe Parallel	G½" (BSPP ⁽⁵⁾ female) up to 4	50 ln/min
Inlet section	None requ	iired		

	Mounting	orientation
--	----------	-------------

Electrical connector(s) on device

Safety	
Valve (GSC only)	Normally closed when powered-off

Test pressure 16 bar a

Leak rate to external (open valve) <1 x 10-6 mbar l/s He, (on request <1x10-8 mbar l/s He)

Leak rate through (closed valve) $< 1 \times 10-6 \text{ mbar l/s He}$

Ingress protection class IP-50


EMC EN 61326-1

Dimensions Dimensions in

Dimensions in mm	Α	В	С	D ⁽⁶⁾	D ⁽⁷⁾
GSM G1/4"	94	87	25	69	87
GSM G½"	145	87	35	79	97
GSC G¼"	124	117	25	69	87
GSC G½"	170	117	35	79	97
GSC G½" valve type(8)	186.4	117	35	79	97
⁶ Standard version ⁷ Profinet	RT/Ethe	rCAT ve	rsion 8x	DV = Do	uble Valv

Additional option: Sub-D9pin female for ProfiBus, 2xRJ45 (In/Out) for Profinet RT, or EtherCAT

Any position (consult manufacturer above 5 bar or vertical mounting)



Type code <red-y smart series>

Instrument type	red-y smart series (Gas)	G :	5					
Function	Meter			М				
	Controller			С				
Full scale of measuring range (air)	Customer-specific (Divider A, up to 600mln/min)				А Х			
defined by manufacturer	Customer-specific (Divider B, up to 6000mln/min)		вх					
	Customer-specific (Divider C, up to 60 In/min)				с х			
	Customer-specific (Divider D, up to 450ln/min)				D X			
nstrument versions	Standard (±1.0% full scale, 1:50)					s		
	Hi-Performance (±0.3% full scale, ±0.5% reading, 1:100)					т		
	Customer-specific / OEM					K		
Materials (body, seals)	Aluminium, FKM**					T	A	
	Aluminium, EPDM						В	
	Stainless steel, FKM	less steel, FKM					s	
	Stainless steel, EPDM						т	
	Customer-specific / OEM						к	
Analog signals (output)	Current 420 mA**						В	
	Current 020 mA						С	
	Voltage 05 V						D	
	Voltage 15 V						E	
	Voltage 010 V			F				
	Voltage 210 V						G	
	Customer-specific / OEM						К	
	Current 420 mA**				П			В
	Current 020 mA							С
	Voltage 05 V							D
	Voltage 15 V							E
	Voltage 010 V							F
	Voltage 210 V							G
	Not defined							N
	Customer-specific / OEM							К
Control valve (integrated)	Type 0.1							2
efined by manufacturer	Type 0.2							2
	Type 0.5							2
	Type 1.2							2
	Type 2.4 DV***							5
	Type 4.5				\Box			1
	Type 8.0 DV***							1
	Type EQP							1
	Type EQP DV***				П			2
	Valve not defined				Ħ			8
	Valve mounted							9
	Customer-specific / OEM							9 !
	No valve							0 (

Type code

G S -

^{**}Standard

^{***}DV = Double Valve

Worldwide TASi Flow Network



Vögtlin Sales & Service Hub North America:

Sierra Instruments

20 Ryan Ranch Road, Suite 109 Monterev. CA 93940. USA

Phone +1 800 866 0200 Fax +1 831 373 4402

sales@sierrainstruments.com www.sierrainstruments.com

International Headquarter:

Vögtlin Instruments GmbH

St. Jakob-Strasse 84 4132 Muttenz Switzerland

Phone +41 61 756 63 00

info@voegtlin.com www.voegtlin.com Vögtlin Sales & Service Hub China:

KEM flow technology (Beijing) Co., Ltd.

Rm. 906, Block C, Ruipu Office Bldg, No. 15, HongJunYingNan Road, Chaoyang District, Beijing 100012, China

Phone +86 10 849 29567

info@kem-kueppers.cn www.voegtlin.cn

Find your local Vögtlin sales partner on our website:

www.voegtlin.com



Vögtlin Instruments GmbH – gas flow technology

St. Jakob-Strasse 84 | CH-4132 Muttenz Phone +41 61 756 63 00 www.voegtlin.com | info@voegtlin.com

